


# Zéfal<sup>®</sup>

KEEP ON RIDING

# BIG AIR HEAVY DUTY FLOOR PUMP


## INSTRUCTIONS

### STEP 1: identify valve type.



**SCHRADER VALVE**  
no adapter needed

WHEEL



**VALVE ADAPTER**  
located under thumb lock lever

**PRESTA VALVE**

WHEEL

### STEP 2: Attach pump head to valve stem



Flip the lever to lock pump head onto the valve stem.  
(Schrader valve shown)

WHEEL

### Lubrication

Periodically lubricate the pump barrel with a couple of drops of oil.



[usa.zefal.com](http://usa.zefal.com)

PRODUCT INFORMATION | INSTRUCTIONS | CUSTOMER SERVICE

For customer assistance call  
**800-278-2565**